

*bd*GDB

JTAG debug interface for GNU Debugger

PAST



User Manual

Manual Version 1.00 for BDI3000

abatron

©1997-2008 by Abatron AG


1 Introduction	3
1.1 BDI3000.....	3
1.2 BDI Configuration	4
2 Installation	5
2.1 Connecting the BDI3000 to Target	5
2.2 Connecting the BDI3000 to Power Supply	7
2.3 Status LED «MODE».....	8
2.4 Connecting the BDI3000 to Host	9
2.4.1 Serial line communication	9
2.4.2 Ethernet communication	10
2.5 Installation of the Configuration Software	11
2.5.1 Configuration with a Linux / Unix host.....	12
2.5.2 Configuration with a Windows host.....	14
2.5.3 Configuration via Telnet / TFTP	16
2.6 Testing the BDI3000 to host connection.....	18
2.7 TFTP server for Windows	18
3 Using bdiGDB	19
3.1 Principle of operation.....	19
3.2 Configuration File	20
3.2.1 Part [INIT].....	21
3.2.2 Part [TARGET]	23
3.2.3 Part [HOST].....	27
3.2.4 Part [FLASH]	29
3.2.5 Part [REGS]	34
3.3 Debugging with GDB	36
3.3.1 Target setup	36
3.3.2 Connecting to the target.....	36
3.3.3 GDB monitor command.....	37
3.3.4 Target serial I/O via BDI.....	38
3.4 Telnet Interface.....	39
3.5 Multi-Core Support	41
3.6 Low level JTAG mode	42
4 Specifications	43
5 Environmental notice.....	44
6 Declaration of Conformity (CE).....	44
7 Warranty.....	45
 Appendices	
A Troubleshooting	46
B Maintenance.....	47
C Trademarks	47

1 Introduction

bdiGDB enhances the GNU debugger (GDB), with JTAG/COP debugging for P.A. Semi PA6T based targets. With the built-in Ethernet interface you get a very fast code download speed. No target communication channel (e.g. serial line) is wasted for debugging purposes. Even better, you can use fast Ethernet debugging with target systems without network capability. The host to BDI communication uses the standard GDB remote protocol.

An additional Telnet interface is available for special debug tasks (e.g. force a hardware reset, program flash memory).

The following figure shows how the BDI3000 interface is connected between the host and the target:



1.1 BDI3000

The BDI3000 is the main part of the bdiGDB system. This small box implements the interface between the JTAG pins of the target CPU and a 10/100Base-T Ethernet connector. The firmware of the BDI3000 can be updated by the user with a simple Linux/Windows configuration program or interactively via Telnet/TFTP. The BDI3000 supports 1.2 – 5.0 Volts target systems.

1.2 BDI Configuration

As an initial setup, the IP address of the BDI3000, the IP address of the host with the configuration file and the name of the configuration file is stored within the flash of the BDI3000. Every time the BDI3000 is powered on, it reads the configuration file via TFTP.

Following an example of a typical configuration file:

```
;bdiGDB configuration file for PA6T-1682
;-----
;
;
[INIT]
;
; Test the EXEC init list entry, load r3 with a pattern
;EXEC    0x7c7a4aa6  0x123456789abcdef0  ; mfspr r3,HSRR0
;

[TARGET]
CPUYPE    PA6T                ;the CPU type
;CPUYPE    PA6T  32BIT        ;the CPU type, 32-bit GDB protocol
JTAGCLOCK 1                   ;use 16 MHz JTAG clock
POWERUP   2000                ;start delay after power-up detected in ms
RESET     HARD 1000           ;assert reset pin for 1 second
WAKEUP    200                 ;give reset time to complete
;STARTUP  RUN                 ;let the CPU run
STARTUP   STOP 8000          ;let boot code setup the system
;STARTUP  HALT                ;halt at boot vector
BREAKMODE HARD                ;SOFT or HARD, HARD uses PPC hardware breakpoint
;STEPMODE JTAG                ;JTAG or HWBP, HWPB uses a hardware breakpoint
STEPMODE  HWBP                ;JTAG or HWBP, HWPB uses a hardware breakpoint
;
CATCH     MCHK HDEC DEC EXT ILLG PRIV FPUN VXUN SC ALNG ; catch some exceptions
;

[HOST]
IP        151.120.25.112
FILE      E:\temp\dump1024k.bin
FORMAT    BIN 0x00010000
PROMPT    PA6T>

[FLASH]
; only to test execution of target code
WORKSPACE 0x0001000          ;workspace in SDRAM
CHIPTYPE   AM29BX16          ;Flash type
CHIPSIZE   0x00800000        ;The size of one flash chip in bytes
BUSWIDTH   16                ;The width of the flash memory bus in bits
FILE       E:\temp\dump16k.bin
FORMAT     BIN 0x00100000

[REGS]
FILE       $regPA6T.def
```

Based on the information in the configuration file, the target is automatically initialized after every re-set.


2 Installation

2.1 Connecting the BDI3000 to Target

The cable to the target system is a 16 pin flat ribbon cable. In case where the target system has an appropriate connector, the cable can be directly connected. The pin assignment is in accordance with the PowerPC COP connector specification.



In order to ensure reliable operation of the BDI (EMC, runtimes, etc.) the target cable length must not exceed 20 cm (8").



For BDI TARGET B connector signals see table on next page.

Warning:

Before you can use the BDI3000 with an other target processor type (e.g. PPC <--> ARM), a new setup has to be done (see chapter 2.5). During this process the target cable must be disconnected from the target system.



To avoid data line conflicts, the BDI3000 must be disconnected from the target system while programming a new firmware for an other target CPU.

BDI TARGET B Connector Signals:

Pin	Name	Description
1	TDO	JTAG Test Data Out This input to the BDI3000 connects to the target TDO pin.
2	<reserved>	
3	TDI	JTAG Test Data In This output of the BDI3000 connects to the target TDI pin.
4	$\overline{\text{TRST}}$	JTAG Test Reset This output of the BDI3000 resets the JTAG TAP controller on the target.
5	<reserved>	
6	Vcc Target	1.2 – 5.0V: This is the target reference voltage. It indicates that the target has power and it is also used to create the logic-level reference for the input comparators. It also controls the output logic levels to the target. It is normally fed from Vdd I/O on the target board.
7	TCK	JTAG Test Clock This output of the BDI3000 connects to the target TCK pin.
8	<reseved>	
9	TMS	JTAG Test Mode Select This output of the BDI3000 connects to the target TMS line.
10	<reseved>	
11	<reserved>	
12	GROUND	System Ground
13	$\overline{\text{RESET}}$	Reset This open collector output of the BDI2000 connects to the target RESET pin.
14	<reseved>	
15	<reserved>	
16	GROUND	System Ground

2.2 Connecting the BDI3000 to Power Supply


The BDI3000 needs to be supplied with the enclosed power supply from Abatron (5VDC).



Before use, check if the mains voltage is in accordance with the input voltage printed on power supply. Make sure that, while operating, the power supply is not covered up and not situated near a heater or in direct sun light. Dry location use only.



For error-free operation, the power supply to the BDI3000 must be between 4.75V and 5.25V DC. **The maximal tolerable supply voltage is 5.25 VDC. Any higher voltage or a wrong polarity might destroy the electronics.**




The green LED «BDI» marked light up when 5V power is connected to the BDI3000

Please switch on the system in the following sequence:

- 1 -> external power supply
- 2 -> target system

2.3 Status LED «MODE»

The built in LED indicates the following BDI states:




MODE LED	BDI STATES
OFF	The BDI is ready for use, the firmware is already loaded.
ON	The output voltage from the power supply is too low.
BLINK	The BDI «loader mode» is active (an invalid firmware is loaded or loading firmware is active).

2.4 Connecting the BDI3000 to Host

2.4.1 Serial line communication


Serial line communication is only used for the initial configuration of the bdiGDB system.

The host is connected to the BDI through the serial interface (COM1...COM4). The communication cable (included) between BDI and Host is a serial cable. There is the same connector pinout for the BDI and for the Host side (Refer to Figure below).



2.4.2 Ethernet communication

The BDI3000 has a built-in 10/100 BASE-T Ethernet interface (see figure below). Connect an UTP (Unshielded Twisted Pair) cable to the BDI3000. Contact your network administrator if you have questions about the network.



The following explains the meanings of the built-in LED lights:

LED	Function	Description
LED 1 (green)	Link / Activity	When this LED light is ON, data link is successful between the UTP port of the BDI3000 and the hub to which it is connected. The LED blinks when the BDI3000 is receiving or transmitting data.
LED 2 (amber)	Speed	When this LED light is ON, 100Mb/s mode is selected (default). When this LED light is OFF, 10Mb/s mode is selected

2.5 Installation of the Configuration Software

On the enclosed diskette you will find the BDI configuration software and the firmware required for the BDI3000. For Windows users there is also a TFTP server included.

The following files are on the diskette.

b30pa6gd.exe	Windows Configuration program
b30pa6gd.xxx	Firmware for the BDI3000
ftpsrv.exe	TFTP server for Windows (WIN32 console application)
*.cfg	Configuration files
*.def	Register definition files
bdisetup.zip	ZIP Archive with the Setup Tool sources for Linux / UNIX hosts.

Overview of an installation / configuration process:

- Create a new directory on your hard disk
- Copy the entire contents of the enclosed diskette into this directory
- Linux only: extract the setup tool sources and build the setup tool
- Use the setup tool or Telnet (default IP) to load/update the BDI firmware
Note: A new BDI has no firmware loaded.
- Use the setup tool or Telnet (default IP) to load the initial configuration parameters
 - IP address of the BDI.
 - IP address of the host with the configuration file.
 - Name of the configuration file. This file is accessed via TFTP.
 - Optional network parameters (subnet mask, default gateway).

Activating BOOTP:

The BDI can get the network configuration and the name of the configuration file also via BOOTP. For this simply enter 0.0.0.0 as the BDI's IP address (see following chapters). If present, the subnet mask and the default gateway (router) is taken from the BOOTP vendor-specific field as defined in RFC 1533.

With the Linux setup tool, simply use the default parameters for the -c option:

```
[root@LINUX_1 bdisetup]# ./bdisetup -c -p/dev/ttyS0 -b57
```

The MAC address is derived from the serial number as follows:

MAC: 00-0C-01-xx-xx-xx , replace the xx-xx-xx with the 6 left digits of the serial number

Example: SN# 33123407 ==>> 00-0C-01-33-12-34

Default IP: 192.168.53.72

Before the BDI is configured the first time, it has a default IP of 192.168.53.72 that allows an initial configuration via Ethernet (Telnet or Setup Tools). If your host is not able to connect to this default IP, then the initial configuration has to be done via the serial connection.

2.5.1 Configuration with a Linux / Unix host

The firmware update and the initial configuration of the BDI3000 is done with a command line utility. In the ZIP Archive bdisetup.zip are all sources to build this utility. More information about this utility can be found at the top in the bdisetup.c source file. There is also a make file included. Starting the tool without any parameter displays information about the syntax and parameters.



To avoid data line conflicts, the BDI3000 must be disconnected from the target system while programming the firmware for an other target CPU family.

Following the steps to bring-up a new BDI3000:

1. Build the setup tool:

The setup tool is delivered only as source files. This allows to build the tool on any Linux / Unix host. To build the tool, simply start the make utility.

```
[root@LINUX_1 bdisetup]# make
cc -O2 -c -o bdisetup.o bdisetup.c
cc -O2 -c -o bdicnf.o bdicnf.c
cc -O2 -c -o bdidll.o bdidll.c
cc -s bdisetup.o bdicnf.o bdidll.o -o bdisetup
```

2. Check the serial connection to the BDI:

With "bdisetup -v" you may check the serial connection to the BDI. The BDI will respond with information about the current loaded firmware and network configuration.

Note: Login as root, otherwise you probably have no access to the serial port.

```
$ ./bdisetup -v -p/dev/ttyS0 -b115
BDI Type : BDI3000 (SN: 30000154)
Loader   : V1.00
Firmware : unknown
MAC      : ff-ff-ff-ff-ff-ff
IP Addr  : 255.255.255.255
Subnet   : 255.255.255.255
Gateway  : 255.255.255.255
Host IP  : 255.255.255.255
Config   : ŸŸŸŸŸŸŸŸ.....
```

3. Load/Update the BDI firmware:

With "bdisetup -u" the firmware is programmed into the BDI3000 flash memory. This configures the BDI for the target you are using. Based on the parameters -a and -t, the tool selects the correct firmware file. If the firmware file is in the same directory as the setup tool, there is no need to enter a -d parameter.

```
$ ./bdisetup -u -p/dev/ttyS0 -b115 -aGDB -tPA6T
Connecting to BDI loader
Programming firmware with ./b30pwsqd.100
Erasing firmware flash ....
Erasing firmware flash passed
Programming firmware flash ....
Programming firmware flash passed
```

4. Transmit the initial configuration parameters:

With "bdisetup -c" the configuration parameters are written to the flash memory within the BDI. The following parameters are used to configure the BDI:

BDI IP Address	The IP address for the BDI3000. Ask your network administrator for assigning an IP address to this BDI3000. Every BDI3000 in your network needs a different IP address.
Subnet Mask	The subnet mask of the network where the BDI is connected to. A subnet mask of 255.255.255.255 disables the gateway feature. Ask your network administrator for the correct subnet mask. If the BDI and the host are in the same subnet, it is not necessary to enter a subnet mask.
Default Gateway	Enter the IP address of the default gateway. Ask your network administrator for the correct gateway IP address. If the gateway feature is disabled, you may enter 255.255.255.255 or any other value.
Config - Host IP Address	Enter the IP address of the host with the configuration file. The configuration file is automatically read by the BDI3000 after every start-up.
Configuration file	Enter the full path and name of the configuration file. This file is read via TFTP. Keep in mind that TFTP has it's own root directory (usual /tftpboot). You can simply copy the configuration file to this directory and the use the file name without any path. For more information about TFTP use "man tftpd".

```
$ ./bdisetup -c -p/dev/ttyS0 -b115 \  
> -i151.120.25.102 \  
> -h151.120.25.112 \  
> -fe:/bdi3000/mytarget.cfg  
Connecting to BDI loader  
Writing network configuration  
Configuration passed
```

5. Check configuration and exit loader mode:

The BDI is in loader mode when there is no valid firmware loaded or you connect to it with the setup tool. While in loader mode, the Mode LED is blinking. The BDI will not respond to network requests while in loader mode. To exit loader mode, the "bdisetup -v -s" can be used. You may also power-off the BDI, wait some time (1min.) and power-on it again to exit loader mode.

```
$ ./bdisetup -v -p/dev/ttyS0 -b115 -s  
BDI Type : BDI3000 (SN: 30000154)  
Loader   : V1.00  
Firmware : V1.00 bdiGDB for PA6T  
MAC      : 00-0c-01-30-00-01  
IP Addr  : 151.120.25.102  
Subnet   : 255.255.255.255  
Gateway  : 255.255.255.255  
Host IP  : 151.120.25.112  
Config   : /bdi3000/mytarget.cfg
```

The Mode LED should go off, and you can try to connect to the BDI via Telnet.


```
$ telnet 151.120.25.102
```

2.5.2 Configuration with a Windows host

First make sure that the BDI is properly connected (see Chapter 2.1 to 2.4).



To avoid data line conflicts, the BDI3000 must be disconnected from the target system while programming the firmware for an other target CPU family.



dialog box «BDI3000 Update/Setup»

Before you can use the BDI3000 together with the GNU debugger, you must store the initial configuration parameters in the BDI3000 flash memory. The following options allow you to do this:

- Port Select the communication port where the BDI3000 is connected during this setup session. If you select Network, make sure the Loader is already active (Mode LED blinking). If there is already a firmware loaded and running, use the Telnet command "boot loader" to activate Loader Mode.
- Speed Select the baudrate used to communicate with the BDI3000 loader during this setup session.
- Connect Click on this button to establish a connection with the BDI3000 loader. Once connected, the BDI3000 remains in loader mode until it is restarted or this dialog box is closed.
- Current Press this button to read back the current loaded BDI3000 firmware version. The current firmware version will be displayed.

Erase	Press this button to erase the current loaded firmware.
Update	This button is only active if there is a newer firmware version present in the execution directory of the bdiGDB setup software. Press this button to write the new firmware into the BDI3000 flash memory.
BDI IP Address	Enter the IP address for the BDI3000. Use the following format: xxx.xxx.xxx.xxx e.g.151.120.25.101 Ask your network administrator for assigning an IP address to this BDI3000. Every BDI3000 in your network needs a different IP address.
Subnet Mask	Enter the subnet mask of the network where the BDI is connected to. Use the following format: xxx.xxx.xxx.xxe.g.255.255.255.0 A subnet mask of 255.255.255.255 disables the gateway feature. Ask your network administrator for the correct subnet mask.
Default Gateway	Enter the IP address of the default gateway. Ask your network administrator for the correct gateway IP address. If the gateway feature is disabled, you may enter 255.255.255.255 or any other value.
Config - Host IP Address	Enter the IP address of the host with the configuration file. The configuration file is automatically read by the BDI3000 after every start-up.
Configuration file	Enter the full path and name of the configuration file. This name is transmitted to the TFTP server when reading the configuration file.
Transmit	Click on this button to store the configuration in the BDI3000 flash memory.

Note:

Using this setup tool via the Network channel is only possible if the BDI3000 is already in Loader mode (Mode LED blinking). To force Loader mode, enter "boot loader" at the Telnet. The setup tool tries first to establish a connection to the Loader via the IP address present in the "BDI IP Address" entry field. If there is no connection established after a time-out, it tries to connect to the default IP (192.168.53.72).

2.5.3 Configuration via Telnet / TFTP

The firmware update and the initial configuration of the BDI3000 can also be done interactively via a Telnet connection and a running TFTP server on the host with the firmware file. In cases where it is not possible to connect to the default IP, the initial setup has to be done via a serial connection.



To avoid data line conflicts, the BDI3000 must be disconnected from the target system while programming the firmware for an other target CPU family.

Following the steps to bring-up a new BDI3000 or updating the firmware.

Connect to the BDI Loader via Telnet.

If a firmware is already running enter "boot loader" and reconnect via Telnet.

```
$ telnet 192.168.53.72
or
$ telnet <your BDI IP address>
```

Update the network parameters so it matches your needs:

```
LDR>network
BDI MAC      : 00-0c-01-30-00-01
BDI IP       : 192.168.53.72
BDI Subnet   : 255.255.255.0
BDI Gateway  : 255.255.255.255
Config IP    : 255.255.255.255
Config File  :
```

```
LDR>netip 151.120.25.102
LDR>nethost 151.120.25.112
LDR>netfile /bdi3000/mytarget.cfg
```

```
LDR>network
BDI MAC      : 00-0c-01-30-00-01
BDI IP       : 151.120.25.102
BDI Subnet   : 255.255.255.0
BDI Gateway  : 255.255.255.255
Config IP    : 151.120.25.112
Config File  : /bdi3000/mytarget.cfg
```

```
LDR>network save
saving network configuration ... passed
BDI MAC      : 00-0c-01-30-00-01
BDI IP       : 151.120.25.102
BDI Subnet   : 255.255.255.0
BDI Gateway  : 255.255.255.255
Config IP    : 151.120.25.112
Config File  : /bdi3000/mytarget.cfg
```

In case the subnet has changed, reboot before trying to load the firmware

```
LDR>boot loader
```

Connect again via Telnet and program the firmware into the BDI flash:

```
$ telnet 151.120.25.102
```

```
LDR>info
  BDI Firmware: not loaded
  BDI CPLD ID : 01285043
  BDI CPLD UES: ffffffff
  BDI MAC      : 00-0c-01-30-00-01
  BDI IP       : 151.120.25.102
  BDI Subnet   : 255.255.255.0
  BDI Gateway  : 255.255.255.255
  Config IP    : 151.120.25.112
  Config File  : /bdi3000/mytarget.cfg
```

```
LDR>fwload e:/temp/b30pwsqd.100
erasing firmware flash ... passed
programming firmware flash ... passed
```

```
LDR>info
  BDI Firmware: 46 / 1.00
  BDI CPLD ID : 01285043
  BDI CPLD UES: ffffffff
  BDI MAC      : 00-0c-01-30-00-01
  BDI IP       : 151.120.25.102
  BDI Subnet   : 255.255.255.0
  BDI Gateway  : 255.255.255.255
  Config IP    : 151.120.25.112
  Config File  : /bdi3000/mytarget.cfg
LDR>
```

To boot now into the firmware use:

```
LDR>boot
```

The Mode LED should go off, and you can try to connect to the BDI again via Telnet.

```
telnet 151.120.25.102
```

2.6 Testing the BDI3000 to host connection

After the initial setup is done, you can test the communication between the host and the BDI3000. There is no need for a target configuration file and no TFTP server is needed on the host.

- If not already done, connect the BDI3000 system to the network.
- Power-up the BDI3000.
- Start a Telnet client on the host and connect to the BDI3000 (the IP address you entered during initial configuration).
- If everything is okay, a sign on message like «BDI Debugger for Embedded PowerPC» and a list of the available commands should be displayed in the Telnet window.

2.7 TFTP server for Windows

The bdiGDB system uses TFTP to access the configuration file and to load the application program. Because there is no TFTP server bundled with Windows, Abatron provides a TFTP server application **tftpsrv.exe**. This WIN32 console application runs as normal user application (not as a system service).

Command line syntax: `tftpsrv [p] [w] [dRootDirectory]`

Without any parameter, the server starts in read-only mode. This means, only read access request from the client are granted. This is the normal working mode. The bdiGDB system needs only read access to the configuration and program files.

The parameter [p] enables protocol output to the console window. Try it.

The parameter [w] enables write accesses to the host file system.

The parameter [d] allows to define a root directory.

<code>tftpsrv p</code>	Starts the TFTP server and enables protocol output
<code>tftpsrv p w</code>	Starts the TFTP server, enables protocol output and write accesses are allowed.
<code>tftpsrv dC:\tftp\</code>	Starts the TFTP server and allows only access to files in C:\tftp and its subdirectories. As file name, use relative names. For example "bdi\mpc7450.cfg" accesses "C:\tftp\bdi\mpc7450.cfg"


You may enter the TFTP server into the Startup group so the server is started every time you login.

3 Using bdiGDB

3.1 Principle of operation

The firmware within the BDI handles the GDB request and accesses the target memory or registers via the JTAG interface. There is no need for any debug software on the target system. After loading the code via TFTP, debugging can begin at the very first assembler statement.

Whenever the BDI system is powered-up the following sequence starts:



3.2 Configuration File

The configuration file is automatically read by the BDI after every power on. The syntax of this file is as follows:

```

; comment
[part name]
identifier parameter1 parameter2 ..... parameterN ; comment
identifier parameter1 parameter2 ..... parameterN
.....
[part name]
identifier parameter1 parameter2 ..... parameterN
identifier parameter1 parameter2 ..... parameterN
.....
                etc.
    
```

Numeric parameters can be entered as decimal (e.g. 700) or as hexadecimal (0x80000).

Note about how to enter 64bit values:

The syntax for 64 bit parameters is : [<high word>_]<low word>
 Hex values may also be entered as: 0xnxxxxxxxxxxxxxxxxn

The "high word" (optional) and "low word" can be entered as decimal or hexadecimal. They are handled as two separate values concatenated with an underscore.

Examples:

```

0x0123456789abcdef           =>>     0x0123456789abcdef
0x01234567_0x89abcdef       =>>     0x0123456789abcdef
1_0                           =>>     0x0000000100000000
256                           =>>     0x0000000000000100
3_0x1234                      =>>     0x0000000300001234
0x80000000_0                 =>>     0x8000000000000000
    
```

3.2.1 Part [INIT]

The part [INIT] defines a list of commands which should be executed every time the target comes out of reset. The commands are used to get the target ready for loading the program file.

- WGPR register value** Write value to the selected general purpose register.
 register the register number 0 .. 31
 value the value to write into the register
 Example: WGPR 0 5
- WSPR register value** Write value to the selected special purpose register.
 register the register number
 value the value to write into the register
 Example: WSPR 318 0x0000000000000002 ;set LPCR[RMI]
- WREG name value** Write value to the selected CPU register by name
 name the register name (MSR,CR,PC)
 value the value to write into the register
 Example: WREG MSR 0x00001002
- DELAY value** Delay for the selected time. A delay may be necessary to let the clock PLL lock again after a new clock rate is selected.
 value the delay time in milliseconds (1...30000)
 Example: DELAY 500 ; delay for 0.5 seconds
- WM8 addr data** Write a byte (8bit) to the selected memory place.
 addr the memory address
 data the value to write to the target memory
 Example: WM8 0xFFFFFA21 0x04 ; SYPCR: watchdog disable ...
- WM16 addr data [SWAP]** Write a half word (16bit) to the selected memory place.
 addr the memory address
 data the value to write to the target memory
 Example: WM16 0x02200200 0x0002 ; TBSCR
- WM32 addr data [SWAP]** Write a word (32bit) to the selected memory place.
 addr the memory address
 data the value to write to the target memory
 Example: WM32 0xe0008100 0x00700000 SWAP ;!2c_l2ccfg_gen
- WM64 addr data** Write a double word (64bit) to the selected memory place.
 addr the memory address
 data the value used to generate the pattern
 Example: WM64 0xfd000000 0x0123456789abcdef

RM8 addr	Read a byte (8bit) from the selected memory place. addr the memory address Example: RM8 0x00000000
RM16 addr	Read a half word (16bit) from the selected memory place. addr the memory address Example: RM16 0x00000000
RM32 addr	Read a word (32bit) from the selected memory place. addr the memory address Example: RM32 0x00000000
RM64 addr	Read a double word (64bit) from the selected memory place. addr the memory address Example: RM64 0x00000000
MMAP start end	Because a memory access to an invalid memory space via JTAG can lead to a deadlock, this entry can be used to define up to 32 valid memory ranges. If at least one memory range is defined, the BDI checks against this range(s) and avoids accessing of not mapped memory ranges. start the start address of a valid memory range end the end address of this memory range Example: MMAP 0xFFE00000 0xFFFFFFFF ;Boot ROM
EXEC opcode [data]	This entry cause the processor to execute one instruction. The optional second parameter defines the data to be stored in HSRR0 before executing the instruction. The original HSRR0 content will be restored. opcode opcode of the instruction data value for HSRR0 Example: EXEC 0x7c7a4aa6 0x123456789abcdef0 ; mfspr r3,HSRR0

The following entries allows to override the Boot Configuration normally stored in the Boot flash at address 0xff02000. If at least one of these entry is present and STARTUP mode is HALT, the boot ROM configuration is skipped and the core is held in reset until all CFG entries are processed.

!!! Be careful, incorrect values could cause the part to fail !!!

CFG16 addr data [SWAP] Write a half word (16bit) to the selected memory place via TBUS.
 addr the memory address
 data the value to write to the target memory

CFG32 addr data [SWAP] Write a word (32bit) to the selected memory place via TBUS.
 addr the memory address
 data the value to write to the target memory
 Example: CFG32 0xe0018290 0x2b270303 SWAP ;pwr_pwrvid

3.2.2 Part [TARGET]

The part [TARGET] defines some target specific values.

CPUTYPE type [32BIT] This value gives the BDI information about the connected CPU. The optional 32BIT parameter forces the BDI to transfer only 32-bit register values to GDB. This allows to connect with a GDB built for 32-bit PowerPC.

type PA6T
 Example: CPUTYPE PA6T

JTAGCLOCK value With this value you can select the JTAG clock rate the BDI3000 uses when communication with the target CPU.

value 0 = 32 MHz 3 = 8 MHz
 1 = 16 MHz 4 = 5 MHz
 2 = 11 MHz 5 = 4 MHz

Example: CLOCK 1 ; JTAG clock is 16 MHz

Example: STARTUP STOP 3000 ; let the CPU run for 3 seconds

RESET type [time] This parameter selects the type of reset the BDI applies to the target during power-up or when "reset" is entered via Telnet. Default is HARD.

NONE No reset is applied.
 SOFT Reset is forced via the JTAG reset control register.
 COLD Reset is forced via the JTAG reset control register.
 HARD Reset is applied via the COP connector reset pin. The "time" parameter defines the time in milliseconds the BDI asserts the reset signal.

Example: RESET COLD

POWERUP delay When the BDI detects target power-up, RESET is forced immediately. This way no code from a boot ROM is executed after power-up. The value entered in this configuration line is the delay time in milliseconds the BDI waits before it begins JTAG communication. This time should be longer than the on-board reset circuit asserts RESET.

delay the power-up start delay in milliseconds
 Example: POWERUP 5000 ;start delay after power-up

WAKEUP time This entry in the init list allows to define a delay time (in ms) the BDI inserts between releasing the RESET line and starting communicating with the target. This init list entry may be necessary if RESET is delayed on its way to the PA6T reset pin.

time the delay time in milliseconds
 Example: WAKEUP 3000 ; insert 3 sec wake-up time

BDIMODE mode [param] This parameter selects the BDI debugging mode. The following modes are supported:

- LOADONLY** Loads and starts the application core. No debugging via JTAG port.
- AGENT** The debug agent runs within the BDI. There is no need for any debug software on the target. This mode accepts a second parameter. If RUN is entered as a second parameter, the loaded application will be started immediately, otherwise only the PC is set and BDI waits for GDB requests.

Example: `BDIMODE AGENT RUN`

STARTUP mode [runtime]

This parameter selects the target startup mode. The following modes are supported:

- HALT** This default mode forces the target to debug mode immediately out of reset. No code is executed after reset.
- STOP** In this mode, the BDI lets the target execute code for "runtime" milliseconds after reset. This mode is useful when monitor code should initialize the target system.
- RUN** After reset, the target executes code until stopped by the Telnet "halt" command.
- WAIT** This special startup mode allows to force an inactive core immediately to debug mode once it is released from reset.

Example: `STARTUP STOP 3000 ; let the CPU run for 3 seconds`

BREAKMODE mode This parameter defines how GDB requested breakpoints are implemented. The current mode can also be changed via the Telnet interface.

- SOFT** This is the normal mode. Breakpoints are implemented by replacing code with a TRAP instruction.
- HARD** In this mode, the PPC breakpoint hardware is used. Only 2 breakpoint at a time is supported (IABR0/1).

Example: `BREAKMODE HARD`

STEPMODE mode This parameter defines how single step (instruction step) is implemented. The alternate step mode (HWBP) may be useful when stepping instructions that causes a TLB miss exception.

- JTAG** This is the default mode. The single step feature of the PA6T debug interface is used for single stepping..
- HWBP** In this mode, one or two hardware breakpoints are used to implement single stepping.

Example: `STEPMODE HWBP`

- CATCH list** This entry allows to define the events that should trigger a debug mode entry (halting the core). The following events can be fetched:
- MCHK Machine check
 - HDEC Hypervisor decrementer
 - DEC Decrementer
 - EXT External interrupt
 - ILLG Illegal instruction
 - PRIV Privileged instruction
 - FPUN Floating-point unavailable
 - VXUN VMX unavailable
 - SC Sytem call
 - ALNG Alignment
- Example: CATCH MCHK ILLG PRIV
-
- MEMACC mode** This parameter defines how memory is accessed. Either via the core by executing `ld` and `st` instructions or via the TBUS. The current mode can also be changed via the Telnet interface. The following modes are supported:
- CORE The CORE (default) mode requires that the core is halted and makes use of the memory management unit (MMU) and cache.
 - TBUS The TBUS access mode bypasses the MMU and cache.
- Example: MEMACCES CORE
-
- REGLIST list** This parameter defines the registers packet that is sent to GDB in response to a register read command. By default only STD are read and transferred.
- STD The standard register block. The FPR registers are not read from the target but transferred. You can't disable this register group.
 - FPR The floating point registers are read and transferred.
- Example: REGLIST STD FPR ; transfer also FPR's
-
- WORKSPACE address** In order to access the vector registers (VR), the BDI needs a workspace of 16 bytes in target RAM. This because the current release of the BDI firmware uses stuffed `stvx/lvx` instructions to access the VR's. Enter the base address of this RAM area.
- address the address of the RAM area
- Example: WORKSPACE 0x00000080

SIO port [baudrate] When this line is present, a TCP/IP channel is routed to the BDI's RS232 connector. The port parameter defines the TCP port used for this BDI to host communication. You may choose any port except 0 and the default Telnet port (23). On the host, open a Telnet session using this port. Now you should see the UART output in this Telnet session. You can use the normal Telnet connection to the BDI in parallel, they work completely independent. Also input to the UART is implemented.

port The TCP/IP port used for the host communication.

baudrate The BDI supports 2400 ... 115200 baud

Example: SIO 7 9600 ;TCP port for virtual IO

Daisy chained JTAG devices:

The BDI can also handle systems with multiple devices connected to the JTAG scan chain. In order to put the other devices into BYPASS mode and to count for the additional bypass registers, the BDI needs some information about the scan chain layout. Enter the number (count) and total instruction register (irlen) length of the devices present before the PowerPC chip (Predecessor). Enter the appropriate information also for the devices following the PowerPC chip (Successor):

SCANPRED count irlen This value gives the BDI information about JTAG devices present before the PowerPC chip in the JTAG scan chain.

count The number of preceding devices

irlen The sum of the length of all preceding instruction registers (IR).

Example: SCANPRED 1 8 ; one device with an IR length of 8

SCANSUCC count irlen This value gives the BDI information about JTAG devices present after the PowerPC chip in the JTAG scan chain.

count The number of succeeding devices

irlen The sum of the length of all succeeding instruction registers (IR).

Example: SCANSUCC 2 12 ; two device with an IR length of 8+4

3.2.3 Part [HOST]

The part [HOST] defines some host specific values.

IP ipaddress	<p>The IP address of the host.</p> <p>ipaddress the IP address in the form xxx.xxx.xxx.xxx</p> <p>Example: IP 151.120.25.100</p>
FILE filename	<p>The default name of the file that is loaded into RAM using the Telnet 'load' command. This name is used to access the file via TFTP. If the filename starts with a \$, this \$ is replace with the path of the configuration file name.</p> <p>filename the filename including the full path or \$ for relative path.</p> <p>Example: FILE F:\gnu\demo\ppc\test.elf FILE \$test.elf</p>
FORMAT format [offset]	<p>The format of the image file and an optional load address offset. If the image is already stored in ROM on the target, select ROM as the format. The optional parameter "offset" is added to any load address read from the image file.</p> <p>format SREC, BIN, AOUT, ELF or ROM</p> <p>Example: FORMAT ELF FORMAT ELF 0x10000</p>
LOAD mode	<p>In Agent mode, this parameters defines if the code is loaded automatically after every reset.</p> <p>mode AUTO, MANUAL</p> <p>Example: LOAD MANUAL</p>
START address	<p>The address where to start the program file. If this value is not defined and the core is not in ROM, the address is taken from the image file. If this value is not defined and the core is already in ROM, the PC will not be set before starting the program file. This means, the program starts at the normal reset address (0xFFF00100).</p> <p>address the address where to start the program file</p> <p>Example: START 0x1000</p>
DEBUGPORT port [RECONNECT]	<p>The TCP port GDB uses to access the target. If the RECONNECT parameter is present, an open TCP/IP connection (Telnet/GDB) will be closed if there is a connect request from the same host (same IP address).</p> <p>port the TCP port number (default = 2001)</p> <p>Example: DEBUGPORT 2001</p>
PROMPT string	<p>This entry defines a new Telnet prompt. The current prompt can also be changed via the Telnet interface.</p> <p>Example: PROMPT PA6T></p>

DUMP filename	The default file name used for the Telnet DUMP command. filename the filename including the full path Example: DUMP dump.bin
TELNET mode	By default the BDI sends echoes for the received characters and supports command history and line editing. If it should not send echoes and let the Telnet client in "line mode", add this entry to the configuration file. mode ECHO (default), NOECHO or LINE Example: TELNET NOECHO ; use old line mode

3.2.4 Part [FLASH]

The Telnet interface supports programming and erasing of flash memories. The bdiGDB system has to know which type of flash is used, how the chip(s) are connected to the CPU and which sectors to erase in case the ERASE command is entered without any parameter.

- CHIPTYPE** type This parameter defines the type of flash used. It is used to select the correct programming algorithm.
- format AM29F, AM29BX8, AM29BX16, I28BX8, I28BX16, AT49, AT49X8, AT49X16, STRATAX8, STRATAX16, MIRROR, MIRRORX8, MIRRORX16, M58X32, AM29DX16, AM29DX32, SPI1682
- Example: CHIPTYPE AM29F
-
- CHIPSIZE** size The size of **one** flash chip in bytes (e.g. AM29F010 = 0x20000). This value is used to calculate the starting address of the current flash memory bank.
- size the size of one flash chip in bytes
- Example: CHIPSIZE 0x80000
-
- BUSWIDTH** width Enter the width of the memory bus that leads to the flash chips. Do not enter the width of the flash chip itself. The parameter CHIPTYPE carries the information about the number of data lines connected to one flash chip. For example, enter 16 if you are using two AM29F010 to build a 16bit flash memory bank.
- with the width of the flash memory bus in bits (8 | 16 | 32 | 64)
- Example: BUSWIDTH 16
-
- FILE** filename The default name of the file that is programmed into flash using the Telnet 'prog' command. This name is used to access the file via TFTP. If the filename starts with a \$, this \$ is replace with the path of the configuration file name. This name may be overridden interactively at the Telnet interface.
- filename the filename including the full path or \$ for relative path.
- Example: FILE F:\gnu\ppc\bootrom.hex
 FILE \$bootrom.hex
-
- FORMAT** format [offset] The format of the file and an optional address offset. The optional parameter "offset" is added to any load address read from the program file. You get the best programming performance when using a binary format (BIN, AOUT, ELF or IMAGE).
- format SREC, BIN, AOUT, ELF or IMAGE
- Example: FORMAT BIN 0x10000

WORKSPACE address If a workspace is defined, the BDI uses a faster programming algorithm that runs out of RAM on the target system. Otherwise, the algorithm is processed within the BDI. The workspace is used for a 1kByte data buffer and to store the algorithm code. There must be at least 2kBytes of RAM available for this purpose.

address the address of the RAM area

Example: WORKSPACE 0x00000000

ERASE addr [increment count] [mode [wait]]

The flash memory may be individually erased or unlocked via the Telnet interface. In order to make erasing of multiple flash sectors easier, you can enter an erase list. All entries in the erase list will be processed if you enter ERASE at the Telnet prompt without any parameter. This list is also used if you enter UNLOCK at the Telnet without any parameters. With the "increment" and "count" option you can erase multiple equal sized sectors with one entry in the erase list.

address Address of the flash sector, block or chip to erase

increment If present, the address offset to the next flash sector

count If present, the number of equal sized sectors to erase

mode BLOCK, CHIP, UNLOCK

Without this optional parameter, the BDI executes a sector erase. If supported by the chip, you can also specify a block or chip erase. If UNLOCK is defined, this entry is also part of the unlock list. This unlock list is processed if the Telnet UNLOCK command is entered without any parameters.

wait The wait time in ms is only used for the unlock mode. After starting the flash unlock, the BDI waits until it processes the next entry.

Example: ERASE 0xff040000 ;erase sector 4 of flash
 ERASE 0xff060000 ;erase sector 6 of flash
 ERASE 0xff000000 CHIP ;erase whole chip(s)
 ERASE 0xff010000 UNLOCK 100 ;unlock, wait 100ms
 ERASE 0xff000000 0x10000 7 ; erase 7 sectors

Example for the ADS8260 flash memory:

```
[FLASH]
CHIPTYPE I28BX8 ;Flash type
CHIPSIZE 0x200000 ;The size of one flash chip in bytes (e.g. AM29F010 = 0x20000)
BUSWIDTH 32 ;The width of the flash memory bus in bits (8 | 16 | 32 | 64)
WORKSPACE 0x04700000 ;workspace in dual port RAM
FILE E:\gnu\demo\ads8260\bootrom.hex ;The file to program
ERASE 0xFF900000 ;erase sector 4 of flash SIMM (LH28F016SCT)
ERASE 0xFF940000 ;erase sector 5 of flash SIMM
ERASE 0xFF980000 ;erase sector 6 of flash SIMM
ERASE 0xFF9c0000 ;erase sector 7 of flash SIMM
```

The above erase list maybe replaces with:

```
ERASE 0xFF900000 0x40000 4 ; erase sector 4 to 7 of flash SIMM
```

Supported Flash Memories:

There are currently 3 standard flash algorithm supported. The AMD, Intel and Atmel AT49 algorithm. Almost all currently available flash memories can be programmed with one of this algorithm. The flash type selects the appropriate algorithm and gives additional information about the used flash.

- For 8bit only flash: AM29F (MIRROR), I28BX8, AT49
- For 8/16 bit flash in 8bit mode: AM29BX8 (MIRRORX8), I28BX8 (STRATAX8), AT49X8
- For 8/16 bit flash in 16bit mode: AM29BX16 (MIRRORX16), I28BX16 (STRATAX16), AT49X16
- For 16bit only flash: AM29BX16, I28BX16, AT49X16
- For 16/32 bit flash in 16bit mode: AM29DX16
- For 16/32 bit flash in 32bit mode: AM29DX32
- For 32bit only flash: M58X32

Some newer Spansion MirrorBit flashes cannot be programmed with the MIRRORX16 algorithm because of the used unlock address offset. Use S29M32X16 for these flashes.

The AMD and AT49 algorithm are almost the same. The only difference is, that the AT49 algorithm does not check for the AMD status bit 5 (Exceeded Timing Limits).

Only the AMD and AT49 algorithm support chip erase. Block erase is only supported with the AT49 algorithm. If the algorithm does not support the selected mode, sector erase is performed. If the chip does not support the selected mode, erasing will fail. The erase command sequence is different only in the 6th write cycle. Depending on the selected mode, the following data is written in this cycle (see also flash data sheets): 0x10 for chip erase, 0x30 for sector erase, 0x50 for block erase.

To speed up programming of Intel Strata Flash and AMD MirrorBit Flash, an additional algorithm is implemented that makes use of the write buffer. This algorithm needs a workspace, otherwise the standard Intel/AMD algorithm is used.

The following table shows some examples:

Flash	x 8	x 16	x 32	Chipsize
Am29F010	AM29F	-	-	0x020000
Am29F800B	AM29BX8	AM29BX16	-	0x100000
Am29DL323C	AM29BX8	AM29BX16	-	0x400000
Am29PDL128G	-	AM29DX16	AM29DX32	0x01000000
Intel 28F032B3	I28BX8	-	-	0x400000
Intel 28F640J3A	STRATAX8	STRATAX16	-	0x800000
Intel 28F320C3	-	I28BX16	-	0x400000
AT49BV040	AT49	-	-	0x080000
AT49BV1614	AT49X8	AT49X16	-	0x200000
M58BW016BT	-	-	M58X32	0x200000
SST39VF160	-	AT49X16	-	0x200000
Am29LV320M	MIRRORX8	MIRRORX16	-	0x400000

Note:

Some Intel flash chips (e.g. 28F800C3, 28F160C3, 28F320C3) power-up with all blocks in locked state. In order to erase/program those flash chips, use the init list to unlock the appropriate blocks:

```
WM16  0xFFFF0000  0x0060  unlock block 0
WM16  0xFFFF0000  0x00D0
WM16  0xFFFF1000  0x0060  unlock block 1
WM16  0xFFFF1000  0x00D0
      . . . .
WM16  0xFFFF0000  0xFFFF  select read mode
```

or use the Telnet "unlock" command:

```
UNLOCK [<addr> [<delay>]]
```

addr This is the address of the sector (block) to unlock

delay A delay time in milliseconds the BDI waits after sending the unlock command to the flash. For example, clearing all lock-bits of an Intel J3 Strata flash takes up to 0.7 seconds.

If "unlock" is used without any parameter, all sectors in the erase list with the UNLOCK option are processed.

To clear all lock-bits of an Intel J3 Strata flash use for example:

```
BDI> unlock 0xFF000000 1000
```

To erase or unlock multiple, continuous flash sectors (blocks) of the same size, the following Telnet commands can be used:

```
ERASE <addr> <step> <count>
UNLOCK <addr> <step> <count>
```

addr This is the address of the first sector to erase or unlock.

step This value is added to the last used address in order to get to the next sector. In other words, this is the size of one sector in bytes.

count The number of sectors to erase or unlock.

The following example unlocks all 256 sectors of an Intel Strata flash (28F256K3) that is mapped to 0x00000000. In case there are two flash chips to get a 32bit system, double the "step" parameter.

```
BDI> unlock 0x00000000 0x20000 256
```

The BDI also supports programming the SPI boot flash via the processors "bit-bang" interface. Ask for current supported SPI flash devices.

```
;SPI boot flash SST25VF016B
WORKSPACE 0xfd001000 ;workspace in L2C RAM
CHIPTYPE SPI1682
FILE E:\temp\pa6tboot.bin
FORMAT BIN 0xffff0000
ERASE 0xffff0000 CHIP ;erase all blocks
```


3.2.5 Part [REGS]

In order to make it easier to access target registers via the Telnet interface, the BDI can read in a register definition file. In this file, the user defines a name for the register and how the BDI should access it (e.g. as memory mapped, memory mapped with offset, ...). The name of the register definition file and information for different registers type has to be defined in the configuration file. The register name, type, address/offset/number and size are defined in a separate register definition file.

An entry in the register definition file has the following syntax:

```
name type addr [size [SWAP]]
```

name	The name of the register (max. 15 characters)	
type	The register type	
	GPR	General purpose register
	SPR	Special purpose register
	MM	Absolute direct memory mapped register
	DMM1...DMM4	Relative direct memory mapped register
	IMM1...IMM4	Indirect memory mapped register
addr	The address, offset or number of the register	
size	The size (8, 16, 32) of the register (default is 32)	
SWAP	If present, the bytes of a 16bit or 32bit register are swapped. This is useful to access little endian ordered registers (e.g. PCI bridge configuration registers).	

The following entries are supported in the [REGS] part of the configuration file:

FILE filename	The name of the register definition file. This name is used to access the file via TFTP. The file is loaded once during BDI startup.	
	filename	the filename including the full path
	Example:	FILE C:\bdi\regs\mpc8260.def
DMMn base	This defines the base address of direct memory mapped registers. This base address is added to the individual offset of the register.	
	base	the base address
	Example:	DMM1 0x01000
IMMn addr data	This defines the addresses of the memory mapped address and data registers of indirect memory mapped registers. The address of a IMMn register is first written to "addr" and then the register value is access using "data" as address.	
	addr	the address of the Address register
	data	the address of the Data register
	Example:	DMM1 0x04700000

Remark:

The registers **msr**, **cr**, **iar** and **fpscr** and are predefined.

Example for a register definition:

Entry in the configuration file:

```
[REGS]
FILE      $regPA6T.def
```

The register definition file:

```
;name          type  addr          size
;-----
;
sp              GPR    1
;
amr             SPR    29
asid            SPR    1022
ber             SPR    862
btcr            SPR    978
ctr             SPR    9
ctrl            SPR    152
dabr            SPR    1013
dabr0           SPR    1013
dabr1           SPR    1016
dabrx           SPR    1015
....
;
; Local Bus Control
;
lpctl           MM     0xfcff0400  32 SWAP
lpcelo          MM     0xfcff0404  32 SWAP
lpcehi          MM     0xfcff0408  32 SWAP
....
;
```

Now the defined registers can be accessed by name via the Telnet interface:

```
BDI> rd asid
BDI> rm sprg0 0xFF801801
```

3.3 Debugging with GDB

Because the GDB server runs within the BDI, no debug support has to be linked to your application. There is also no need for any BDI specific changes in the application sources.

3.3.1 Target setup

Target initialization may be done at two places. First with the BDI configuration file, second within the application. The setup in the configuration file must at least enable access to the target memory where the application will be loaded. Disable the watchdog and setting the CPU clock rate should also be done with the BDI configuration file. Application specific initializations like setting the timer rate are best located in the application startup sequence.

3.3.2 Connecting to the target

As soon as the target comes out of reset, BDI initializes it and optionally loads your application code. BDI now waits for GDB request from the debugger running on the host.

After starting the debugger, it must be connected to the remote target. This can be done with the following command at the GDB prompt:

```
(gdb)target remote bdi2000:2001
```

bdi2000	This stands for an IP address. The HOST file must have an appropriate entry. You may also use an IP address in the form xxx.xxx.xxx.xxx
2001	This is the TCP port used to communicate with the BDI

If not already halted, this stops the execution of application code and the target CPU changes to debug mode. Remember, every time the processor is in debug mode, the processor is freezed. During this time, no hardware interrupts will be processed.

Note: For convenience, the GDB detach command triggers a target reset sequence in the BDI.

```
(gdb) ...  
(gdb)detach  
... Wait until BDI has resetet the target and reloaded the image  
(gdb)target remote bdi2000:2001
```

Note:

After loading a program to the target you cannot use the GDB "run" command to start execution. You have to use the GDB "continue" command.

3.3.3 GDB monitor command


The BDI supports the GDB "monitor" command. Telnet commands are executed and the Telnet output is returned to GDB. This way you can for example switch the BDI breakpoint mode from within your GDB session.

```
(gdb) target remote bdi2000:2001
Remote debugging using bdi2000:2001
0x10b2 in start ()
(gdb) monitor break
Breakpoint mode is SOFT
(gdb) mon break hard

(gdb) mon break
Breakpoint mode is HARD
(gdb)
```

3.3.4 Target serial I/O via BDI

A RS232 port of the target can be connected to the RS232 port of the BDI3000. This way it is possible to access the target's serial I/O via a TCP/IP channel. For example, you can connect a Telnet session to the appropriate BDI3000 port. Connecting GDB to a GDB server (stub) running on the target should also be possible.



The configuration parameter "SIO" is used to enable this serial I/O routing. The used framing parameters are 8 data, 1 stop and not parity.

```
[TARGET]
....
SIO 7 9600 ;Enable SIO via TCP port 7 at 9600 baud
```

Warning!!!

Once SIO is enabled, connecting with the setup tool to update the firmware will fail. In this case either disable SIO first or disconnect the BDI from the LAN while updating the firmware.

3.4 Telnet Interface

A Telnet server is integrated within the BDI. The Telnet channel is used by the BDI to output error messages and other information. Also some basic debug commands can be executed.

Telnet Debug features:

- Display and modify memory locations
- Display and modify general and special purpose registers
- Single step a code sequence
- Set hardware breakpoints
- Load a code file from any host
- Start / Stop program execution
- Programming and Erasing Flash memory

During debugging with GDB, the Telnet is mainly used to reboot the target (generate a hardware reset and reload the application code). It may be also useful during the first installation of the bdiGDB system or in case of special debug needs.

Example of a Telnet session:

```
PA6T>reset
- TARGET: processing user reset request
- BDI asserts RESET
- Core#0: ID code is 0x2A000527
- BDI removes RESET
- TARGET: resetting target passed
- TARGET: processing target startup ....
- TARGET: processing target startup passed
PA6T>info
Core number      : 0
Core state       : debug mode
Debug entry cause : debug halt request
Current PC       : 0x00000000fff00100
Current CR       : 0x00000000
Current MSR      : 0x9000000000000000
Current LR       : 0x0000000000000000
PA6T>md 0xffff00100
00000000fff00100 : 48002300 00000000 00000000 00000000 H.#.....
00000000fff00110 : 00000000 00000000 00000000 00000000 .....
00000000fff00120 : 00000000 00000000 00000000 00000000 .....
.....
```

Notes:

The DUMP command uses TFTP to write a binary image to a host file. Writing via TFTP on a Linux/Unix system is only possible if the file already exists and has public write access. Use "man tftpd" to get more information about the TFTP server on your host.

The BI command sets a hardware breakpoint via the IABR register. IABR[TE] must be equal MSR[IR] in order for a match to be signalled. IABR[TE] is set when the parameter V is present in the BREAK-MODE configuration. Otherwise it is cleared. You can override this default setting with the optional parameter v (virtual, sets TE) or p (physical, clears TE).

The Telnet commands:

```
"MD      [<address>] [<count>] display target memory as word (32bit)",
"MDH    [<address>] [<count>] display target memory as half word (16bit)",
"MDB    [<address>] [<count>] display target memory as byte (8bit)",
"MM     <addr> <value> [<cnt>] modify word(s) (32bit) in target memory",
"MMH    <addr> <value> [<cnt>] modify half word(s) (16bit) in target memory",
"MMB    <addr> <value> [<cnt>] modify byte(s) (8bit) in target memory",
"MC     [<address>] [<count>] calculates a checksum over a memory range",
"MV     verifies the last calculated checksum",
"RD     [<name>] display general purpose or user defined register",
"RDUMP  [<file>] dump all user defined register to a file",
"RDFPR  display floating point registers",
"RDSPR  <number> display special purpose register",
"RDVR   [<number>] display vector register",
"RM     {<nbr>|<name>} <value> modify general purpose or user defined register",
"RMSPR  <number> <value> modify special purpose register",
"RMVR   <nbr><val val val val> modify vector register (four 32bit values)",
"IFLUSH flush L1 instruction cache",
"DFLUSH [<addr>] flush L1 data cache (addr = address of cached memory)",
"BOOT   reset the BDI and reload the configuration",
"RESET  [HALT | RUN [time]] reset the target system, change startup mode",
"BREAK  [SOFT | HARD] display or set current breakpoint mode",
"GO     [<pc>] set PC and start target system",
"GO     <n> <n> [<n>[<n>]] start multiple cores in requested order",
"TI     [<pc>] trace on instuction (single step)",
"TC     [<pc>] trace on change of flow",
"HALT   [<n>[<n>[<n>[<n>]]]] force core(s) to enter debug mode (n = core number)",
"BI     <addr> [<mask>] set instruction breakpoint",
"CI     [<id>] clear instruction hardware breakpoint(s)",
"BD     [R|W] <addr> [<mask>] set data breakpoint",
"CD     [<id>] clear data watchpoint(s)",
"INFO   display information about the current state",
"DUMP   <addr> <size> [<file>] dump target memory to a file",
"SPIDUMP <addr> <size> [<file>] dump SPI boot flash content to a file",
"LOAD   [<offset>] [<file> [<format>]] load program file to target memory",
"VERIFY [<offset>] [<file> [<format>]] verify a program file to target memory",
"PROG   [<offset>] [<file> [<format>]] program flash memory",
"       <format> : SREC or BIN or AOUT or ELF",
"ERASE  [<address> [<mode>]] erase a flash memory sector, chip or block",
"       <mode> : CHIP, BLOCK or SECTOR (default is sector)",
"ERASE  <addr> <step> <count> erase multiple flash sectors",
"UNLOCK [<addr> [<delay>]] unlock a flash sector",
"UNLOCK <addr> <step> <count> unlock multiple flash sectors",
"FLASH  <type> <size> <bus> change flash configuration",
"DELAY  <ms> delay for a number of milliseconds",
"MEMACC {CORE | TBUS} change memory access mode",
"SELECT <core> change the current core",
"HOST   <ip> change IP address of program file host",
"PROMPT <string> defines a new prompt string",
"CONFIG display or update BDI configuration",
"CONFIG <file> [<hostIP> [<bdIP> [<gateway> [<mask>]]]]",
"HELP   display command list",
"JTAG   switch to JTAG command mode",
"QUIT   terminate the Telnet session"
```

3.5 Multi-Core Support

The bdiGDB system supports concurrent debugging of the two cores present in the PA6T-1682. For every core you can start its own GDB session. The port numbers used to attach the remote targets are 2001 and 2002. In the Telnet you switch between the cores with the command "select {0 | 1}". In the configuration file, simply begin the line with the appropriate core number. If there is no #n in front of a line, the BDI assumes core #0.

```
[TARGET]
;common configurations
JTAGCLOCK      1          ;use 8 MHz JTAG clock
POWERUP        3000       ;power-up delay
WAKEUP         200        ;delay after releasing reset

;configuration for core #0
#0 CPUTYPE     PA6T
#0 STARUP      HALT       ;halt active core immediately at the reset vector
#0 BREAKMODE   HARD
#0 STEPMODE    HWBP

;configuration for core #1
#1 CPUTYPE     PA6T
#1 STARTUP     WAIT       ;halt core once released from reset
#1 BREAKMODE   HARD
#1 STEPMODE    HWBP
```

Multi-Core related Telnet commands:

```
"SELECT <core>                change the current core",
"GO      <n> <n> [<n>[<n>]]    start multiple cores in requested order",
"HALT    [<n>[<n>[<n>[<n>]]]]   force core(s) to debug mode (n = core number)",
```

3.6 Low level JTAG mode

It is possible to switch to a mode where you can enter low level JTAG commands via the Telnet interface. You activate this mode via the Telnet "jtag" command. Once the BDI has entered this mode, a new set of Telnet commands is available.

```
"TRST      {0|1}          assert (1) or release (0) TRST",
"RESET     {0|1}          assert (1) or release (0) RESET",
"CLK       <count> <tms>  clock TAP with requested TMS value",
"SCAN      <ir> <len> <...b2b1b0> read/xchg a scan chain",
"SCAN2     <ir> <len> <...b2b1b0> read/xchg a scan chain double clocked",
"RIR [+]   <len>         read  IR, zero is scanned in",
"RDR [+]   <len>         read  DR, zero is scanned in",
"WIR [+]   <len> <...b2b1b0> write IR, b0 is first scanned",
"WDR [+]   <len> <...b2b1b0> write DR, b0 is first scanned",
"XIR [+]   <len> <...b2b1b0> xchg IR, b0 is first scanned",
"XDR [+]   <len> <...b2b1b0> xchg DR, b0 is first scanned",
"          +           : more data follows",
"          do not exit shift-IR/DR state",
"          len : the number of bits 1..256",
"          bx  : a data byte, two hex digits",
"DELAY     <10...50000>  delay for n microseconds",
"HELP      display JTAG command list",
"EXIT      terminate JTAG mode"
```

Using this special JTAG mode is not necessary during normal debugging. It helps to investigate JTAG connection problems or to dump some scan chain for special problem analysis.

The following example dumps the SYS_DEBUG scan chain:

```
PA6T#0>jtag
JTAG>scan 0x31 119
7018000000020d200000100c52d96d
JTAG>exit
PA6T#0>
```

4 Specifications

Operating Voltage Limiting	5 VDC \pm 0.25 V
Power Supply Current	typ. 500 mA max. 1000 mA
RS232 Interface: Baud Rates	9'600, 19'200, 38'400, 57'600, 115'200
Data Bits	8
Parity Bits	none
Stop Bits	1
Network Interface	10/100 BASE-T
BDM/JTAG clock	up to 32 MHz
Supported target voltage	1.2 – 5.0 V
Operating Temperature	+ 5 °C ... +60 °C
Storage Temperature	-20 °C ... +65 °C
Relative Humidity (noncondensing)	<90 %rF
Size	160 x 85 x 35 mm
Weight (without cables)	280 g
Host Cable length (RS232)	2.5 m
Electromagnetic Compatibility	CE compliant
Restriction of Hazardous Substances	RoHS 2002/95/EC compliant

Specifications subject to change without notice

5 Environmental notice

Disposal of the equipment must be carried out at a designated disposal site.

6 Declaration of Conformity (CE)


DECLARATION OF CONFORMITY

This declaration is valid for following product:

Type of device: BDM/JTAG Interface
Product name: BDI3000

The signing authorities state, that the above mentioned equipment meets the requirements for emission and immunity according to

EMC Directive 89/336/EEC

The evaluation procedure of conformity was assured according to the following standards:

IEC 61000-6-2: 1999, mod. EN61000-6-2: 2001
IEC 61000-6-3: 1996, mod. EN61000-6-2: 2001

This declaration of conformity is based on the test report no. E1087-05-7a of Quinel, Zug, Swiss Testing Service, accreditation no. STS 037

Manufacturer:

ABATRON AG
Lettenstrasse 9
CH-6343 Rotkreuz

Authority:


Max Vock
Marketing Director


Ruedi Dummermuth
Technical Director

Rotkreuz, 7/18/2007

7 Warranty

ABATRON Switzerland warrants the physical CD, cable and BDI3000 to be free of defects in materials and workmanship for a period of 3 years following the date of purchase when used under normal conditions.

In the event of notification within the warranty period of defects in material or workmanship, ABATRON will replace defective CD, cable or BDI3000. The remedy for breach of this warranty shall be limited to replacement and shall not encompass any other damages, including but not limited loss of profit, special, incidental, consequential, or other similar claims.

ABATRON Switzerland specifically disclaims all other warranties - expressed or implied, including but not limited to implied warranties of merchantability and fitness for particular purposes - with respect to defects in the CD, cable and BDI3000, and the program license granted herein, including without limitation the operation of the program with respect to any particular application, use, or purposes. In no event shall ABATRON be liable for any loss of profit or any other commercial damage, including but not limited to special, incidental, consequential, or other damages.

Failure in handling which leads to defects are not covered under this warranty. The warranty is void under any self-made repair operation.

Appendices

A Troubleshooting

Problem

The firmware can not be loaded.

Possible reasons

- The BDI is not correctly connected with the Host (see chapter 2).
- A wrong communication port is selected (Com 1...Com 4).
- The BDI is not powered up

Problem

No working with the target system (loading firmware is okay).

Possible reasons

- Wrong pin assignment (BDM/JTAG connector) of the target system (see chapter 2).
- Target system initialization is not correctly → enter an appropriate target initialization list.
- An incorrect IP address was entered (BDI3000 configuration)
- BDM/JTAG signals from the target system are not correctly (short-circuit, break, ...).
- The target system is damaged.

Problem

Network processes do not function (loading the firmware was successful)

Possible reasons

- The BDI3000 is not connected or not correctly connected to the network (LAN cable or media converter)
- An incorrect IP address was entered (BDI3000 configuration)

B Maintenance

The BDI needs no special maintenance. Clean the housing with a mild detergent only. Solvents such as gasoline may damage it.

C Trademarks

All trademarks are property of their respective holders.